



GLOBAL Encasement, Inc.


Wet Mil Gauge Instructions

Insert numbered tooth required into freshly applied wet coating system.
The gauge will show the wet mil thickness on the substrate.

Refer to the illustrations below:



Wet Mil Gauge In Coating



Wet Mil Gauge
(Actual Size)



DIRECTIONS FOR USE:

Press gauge into wet coating. Withdraw vertically and note deepest tooth having paint on it and the next higher tooth that is not coated with paint. The true wet film thickness lies between these two readings. Clean gauge with soap and water after each use.

Wet and Dry Film Thickness Formula:

- W = Wet Film Thickness (WFT)
- D = Dry Film Thickness (DFT)
- P = Percentage of Solids by Volume in Coating

$$W = D / P$$

$$D = W \times P$$



WHY REPLACE? – JUST ENCASE!



701 E. Santa Clara Street, Ventura, CA 93001-5972 USA
Worldwide: (800) 266-3982 Fax (800) 520-3291
www.encasement.com